

### PRODUCT DATA RELEASE

Date: April 15, 2013

Contact: Randy Wardell - President

Phone: 954-607-2189

Email: thebuzz@joyoffusing.com Website: www.joyoffusing.com

## F500 - Stackable Fusing Foot Rings - 2 Pack Refill

## This Refill Package Contains 2 Sets of Stackable Fusing Foot Rings Add a Stemmed Foot to Two Different Drape Bowls



#### **Package contains:**

- 2 Sets of Stackable Fusing Foot Rings
- Information Card with instructions on how to use the stackable rings to add a foot to a draped bowl.



Sample Bowl with Stemmed Foot (Rings shown on inset)

The 'Starfire Bowl with Stem Foot' process is simple:

- Create a 10" to 12" (25 to 31 cm) diameter flat-disk design then fuse it to your desired fusing level.
- Cast a 3-1/4" (85 mm) x 1/4" (6 mm) glass disk in the C105 Foot Casting Mold using 90 grams of leftover scrap glass pieces from your project.
- Stack one set of F500 Foot Rings to create the 'V' shaped cone assembly. These precision cut, reinforced rings will retain their thickness and shape throughout the drape firing process.
- Place your pre-fused flat-disk on the M35 Starfire mold, then center the Foot Ring cone assembly and stack the Cast Foot disk on top of the cone.
- Set the kiln to the recommended drape fire schedule (on the instruction card) to shape the bowl, create the stemmed foot profile and fuse the foot all in the same firing.

# Suggested retail price: \$19.95 (US) In Stock and Available Now



Foot Rings must be cut and discarded after one use

Wardell Products P.O. Box 480069, Fort Lauderdale, FL 33348-0069

Email: thebuzz@joyoffusing.com • Ph: 954-607-2189 • Fax: 754-551-5462 • Website: www.joyoffusing.com